



INSTALLATION GUIDE

NVX BE-GM-VETC6-NSW10-4V2 B.O.O.S.T
Series Bass Enclosure for Prius

Step 1

- A) Remove all the contents in the driveside storage compartment.
- B) Using a nylon pry tool, carefully pry the compartment door off the hinges.
Take note: these hinges are plastic and can break with too much force.



Step 2

- A) Place the supplied threaded rod into the bottom of the B.O.O.S.T Box, leaving about a 1/2" exposed. The exposed threaded rod will be used to mark the location to drill for the mounting point.
- B) Using masking tape, tape the bottom of the compartment. (Illustrated in picture below)



Step 3

- A) Place the B.O.O.S.T box into the vehicle, pressing down firmly. This will make an impression in the masking tape. (remove B.O.O.S.T box)
- B) After removing if there is no impression made on the masking tape, back out the threaded rod and repeat step 3.



Step 4

Now with the impression made use a 1/2" drill bit to drill a hole in the floor. Before drilling be sure to check for any fuel lines, brake lines, wire harnesses, or anything that could be damaged.



Step 5

Run wire from the amplifier location to the location of the B.O.O.S.T box and connect it to the terminal.



Congratulations

on the newly found bass using the NVX B.O.O.S.T enclosure

DIFFICULTY LEVEL: 4 out of 10 being the most difficult.



We recommend the installation of the NVX BE-GM-VETC6-NSW10-4V2 to be performed by a professional that will have the skills and tools to ensure the job is done correctly. Please follow the steps above to get the best performance out of the NVX BE-GM-VETC6-NSW10-4V2. Installing and mounting NVX BE-GM-VETC6-NSW10-4V2 improperly can present a serious safety hazard in the event of a collision. If you have any questions regarding installation of this product please feel free to contact NVX directly for further guidance and installation techniques.