

## **Factory Connect Camera System: Toyota Tundra**

Non-JBI Models with Screen

1

## Remove Radio / Multi-media assembly

Unplug factory 20 pin plug and plug into female end of T-Harness. Plug male end of harness into rear of radio.

If radio does not have 20 pin port, this camera is not suitable.

2

## Install

- 1. Remove existing tailgate handle. Transfer lock mechanism. Mount new tailgate handle with camera.
- 2. Route cable from camera out bottom of the tailgate and connect to extension cable. Route cable forward into the cab.
- 3. Connect camera wires according to diagram below.

Connect camera Red wire to suitable ACC 3 or IGN +12V. Ground camera Black wire. Camera Cable 404000 -000000 GND . **NOTES:** Camera must be connected to ACC ACC/IGN or IGN not reverse trigger. We recommend powering the camera at 12 Volt Receptacle



Clearwater, Florida 33760

15500 Lightwave Drive, Suite 202 Woolmer Way, Bordon, Hampshire, GU35 9QE, United Kingdom

EchoMaster is a Power Brand of AAMP Global

EchoMaster.com