



AHDH-HD2

AHDH-HD2

**HONDA HARNESS
USED WITH AHDT-01 AND AHDI-101**

AHDH-HD2

INSTALLATION INSTRUCTIONS

*** READ IMPORTANT WARNING ON PAGE 1
BEFORE ATTEMPTING ANY INSTALLATION**

COMPATIBILITY:

**•Note : The AHDH-HD2 will not work with a
radio that has the 6-disc in dash cd changer.**

The AHDH-HD2 is to be used along with the AHDT-01 HD Tuner and the AHDI-101 import HD radio interface (all sold separately) in the vehicles listed. An iPod may also be connected by using the XIAH-IPC iPod cable (sold separately). The OEM radio will control the functions of the HD Tuner and the iPod through the buttons on the radio. Also for those radios that do not display text, the XIA-LCD display screen (sold separately), may be added to display the HD and iPod text information.

APPLICATIONS:

HONDA

Accord	1994-1997
CRV	1995-1998
Odyssey	1995-1998
Prelude	1995-1998




*IMPORTANT WARNING

THIS PRODUCT INCLUDES INSTRUCTIONS FOR INSTALLATION WHICH MUST BE CAREFULLY FOLLOWED. THE INSTRUCTIONS ARE WORDED IN SUCH A MANNER TO ASSUME THAT THE INSTALLER IS CAPABLE OF COMPLETING THESE TYPE OF ELECTRONIC INSTALLATIONS. IF YOU ARE UNCLEAR AS TO WHAT YOU ARE INSTRUCTED TO DO OR BELIEVE THAT YOU DO NOT UNDERSTAND THE INSTRUCTIONS SO AS TO PROPERLY AND SAFELY COMPLETE THE INSTALLATION YOU SHOULD CONSULT A TECHNICIAN WHO DOES HAVE THIS KNOWLEDGE AND UNDERSTANDING. **FAILURE TO FOLLOW THESE INSTRUCTIONS CAREFULLY AND TO INSTALL THE INTERFACE AS DESCRIBED COULD CAUSE HARM TO THE VEHICLE OR TO SAFETY SYSTEMS ON THE VEHICLE. INTERFERENCE WITH CERTAIN SAFETY SYSTEMS COULD CAUSE HARM TO PERSONS AS WELL. IF YOU HAVE ANY QUESTIONS IN THIS REGARD PLEASE CALL THE HELP LINE OR THE METRA AT 1-800-221-0932 FOR ASSISTANCE.**

PORT OVERVIEW

- 1) This port is used with the optional XIA-LCD display.
- 2) This port is used with the HD cable included with AHDT-01 tuner.
- 3) This port is used with the iPod cable XIAH-IPC or the AUX IN cable XIAH-RCA.



OPERATION

When the AHDH-I01 interface is installed the radio will see the interface as a cd changer. It is recommended to use the XIA-LCD to get the most out of your iPod or HD radio. If there is a factory cd changer already in the vehicle that is not an in dash type, the cd changer will have to be disconnected.

Note: The Acura/Honda radios vary in what buttons they have however this instruction will cover as many buttons as possible. The radios will not have every button described below but the definition of the buttons displayed on the radio will still be valid.

OPERATION IN CD CHANGER MODE

The AHDH-I01 can emulate a factory CD Changer. In this mode, the button operations are re-defined to work with both the iPod and HD radio receiver.

BUTTON	DESCRIPTION OF FUNCTION
CD/CHG	Enters into 'CD Changer' mode & selects the next device. If HD-AM was the previous device that was playing, then HD-FM is selected and vice versa. If an iPod is attached, then it will alternatively be chosen in the following order : HD-AM > iPod > HD-FM > iPod
AM/FM	Deselects 'CD Changer' mode. (HD-AM, HD-FM, or iPod).
SEEK/SKIP	In iPod mode it goes to the next / previous song. In HD mode, seeks to the next/previous channel.
PRESET #5 DISK SEL	In iPod mode, Seek to previous playlist.
PRESET #6 DISK SEL	In iPod mode, Seek to next playlist.

FIRMWARE FOR THE IPOD:

The firmware in your iPod must be the latest revision to operate correctly. Go to Apple.com and check your revision with iPod Update.