



Jeep Renegade Data Interface with SWC & Factory Display Retention 2015

INTERFACE FEATURES

- Provides accessory power (10-amp) (*)
- Designed for non-amplified models
- Provides NAV outputs (parking brake, reverse, speed sense)
- Retains audio controls on the steering wheel
- Retains parking sensor chimes
- Retains balance and fade
- Retains most of the vehicle settings that was displayed on the factory radio *
- Micro-B USB updatable

* **Attention!** The aftermarket radios backup camera input will be used to display the vehicle settings. If the radio doesn't have a backup camera Input, then there will be no visualization of the vehicle settings. An externally mounted screen could be substituted in this situation.

INTERFACE COMPONENTS

- AX-JP901 harness • AX-JP901 interface
- ASWC-1 interface • ASWC-1 harness
- Female 3.5mm connector with stripped leads
- Chime speaker

TABLE OF CONTENTS

Connections	2-3
Installation	3
Programming	3-4
Screen operation.....	4-6

TOOLS & INSTALLATION ACCESSORIES REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink • Tape • Wire cutter
- Zip ties

Product Info



CONNECTIONS

From the aftermarket radio to the AX-JP901 harness:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- If the aftermarket radio has an illumination wire, connect the **Orange** wire to it.
- Connect the **Blue** wire to the power antenna turn-on wire.
- Connect the **White** wire to the left front positive speaker wire.
- Connect the **White/Black** wire to the left front negative speaker wire.
- Connect the **Gray** wire to the right front positive speaker wire.
- Connect the **Gray/Black** wire to the right front negative speaker wire.
- Connect the **Green** wire to the left rear positive speaker wire.
- Connect the **Green/Black** wire to the left rear negative speaker wire.
- Connect the **Purple** wire to the right rear positive speaker wire.
- Connect the **Purple/Black** wire to the right rear negative speaker wire.

The following (3) wires are only for multimedia/navigation radios that require these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.

From the aftermarket radio to the ASWC-1 harness:

This harness is only to be used if the vehicle is equipped with steering wheel controls or a backup camera.

- Connect the **Red** wire to the accessory wire.
- For the radios listed below, connect the *female 3.5mm connector with stripped leads*, to the male 3.5mm SWC jack from the ASWC-1 harness. Any remaining wires tape off and disregard:
 - **Eclipse:** Connect the steering wheel control wire, normally **Brown**, to the **Brown/White** wire of the connector. Then connect the remaining steering wheel control wire, normally **Brown/White**, to the **Brown** wire of the connector.
 - **Metra OE:** Connect the steering wheel control Key 1 wire (Gray) to the **Brown** wire.
 - **Kenwood or select JVC with a steering wheel control wire:** Connect the **Blue/Yellow** wire to the **Brown** wire.
 - **XITE:** Connect the steering wheel control SWC-2 wire from the radio to the **Brown** wire.
 - **Parrot Asteroid Smart or Tablet:** Connect the 3.5mm jack into the AX-SWC-PARROT (sold separately), and then connect the 4-pin connector from the AX-SWC-PARROT into the radio.
- **Universal “2 or 3 wire” radio:** Connect the steering wheel control wire, referred to as Key-A or SWC-1, to the **Brown** wire of the connector. Then connect the remaining steering wheel control wire, referred to as Key-B or SWC-2, to the **Brown/White** wire of the connector. If the radio comes with a third wire for ground, disregard this wire.

Note: The radio must be updated to rev. 2.1.4 or higher software.

Note: After the interface has been programmed to the vehicle, refer to the manual provided with the radio for assigning the SWC buttons. Contact the radio manufacturer for more information.

Continued on the next page

CONNECTIONS *(CONT.)*

- **For all other radios:** Connect the 3.5mm jack from the ASWC-1 harness, into the jack on the aftermarket radio designated for an external steering wheel control interface. Please refer to the aftermarket radios manual if in doubt as to where the 3.5mm jack goes to.
- Connect the **Yellow** male RCA jack labeled “To Reverse Camera Input (Radio)”, to the backup camera input.

Note: The aftermarket radios backup camera input will be used to display the vehicle settings. If the radio doesn't have a backup camera input, then there will be no visualization of the vehicle settings. An externally mounted screen could be substituted in this situation.

- If installing an aftermarket backup camera, connect the **Yellow** female RCA jack labeled “To Reverse Camera”, to the camera.

INSTALLATION

With the key in the off position:

- Connect the AX-JP901 harness to the AX-JP901 interface, and then to the wiring harness in the vehicle.
- Zip tie the chime speaker under the dash to a location where it will be heard clearly by the driver, then route the harness to the radio location.
- Connect the chime speaker to the AX-JP901 Interface.
- Connect the ASWC-1 harness to the ASWC-1 interface, and then to the AX-JP901 interface.

PROGRAMMING

- Press and hold the Volume-Up button on the steering wheel.
- Turn the ignition on, the L.E.D. in the ASWC-1 interface will start flashing rapidly, which means the ASWC-1 is looking for the vehicle and the radio.

Note: If the L.E.D. did not start flashing rapidly, press the reset button for 3 seconds, while still holding the Volume-Up button.

- After a few seconds the L.E.D. should stop flashing rapidly, and then go out for approximately 2 seconds.
- After approximately 2 seconds there will be a series of **7 Green** flashes, some short, and some long. The long flashes represent the wires that are connected to the ASWC-1. The 3rd, 4th, 5th, and 6th flashes should be longer.

Tip: Knowing this will help to troubleshoot, if need be.

- The L.E.D. will pause for another 2 seconds, and then flash **Red** up to 18 times depending on which radio is connected to the ASWC-1. Refer to the L.E.D. feedback section for information.
- This is the end of the auto detection stage. Release from holding the Volume-Up button. If the ASWC-1 detected the vehicle and the radio successfully, the L.E.D. will light up solid.
- Test the steering wheel controls for proper operation. Refer to the ASWC-1 instructions online at axxessinterfaces.com for customizing the buttons, if so desired.

Continued on the next page

L.E.D. feedback

The (18) **Red** L.E.D. flashes represent what brand radio the ASWC-1 believes it is connected to. Each flash represents a different radio manufacturer. For example, if you are installing a JVC radio, the ASWC-1 will flash (5) times. Following is a legend that dictates which manufacturer corresponds to which flash.

L.E.D. feedback legend

1 flash - Eclipse (Type 1) †	10 flashes - Clarion (Type 2) †
2 flashes - Kenwood ‡	11 flashes - Metra OE
3 flashes - Clarion (Type 1) †	12 flashes - Eclipse (Type 2) †
4 flashes - Sony / Dual	13 flashes - LG
5 flashes - JVC	14 flashes - Parrot **
6 flashes - Pioneer / Jensen	15 flashes - XITE
7 flashes - Alpine *	16 flashes - Philips
8 flashes - Visteon	17 flashes - TBD
9 flashes - Valor	18 flashes - JBL

* **Note:** If the ASWC-1 flashes **Red** (7) times, and you do not have an Alpine radio connected to it, that means the ASWC-1 does not detect a radio connected to it. Verify that the 3.5mm jack is connected to the correct steering wheel jack/wire in the radio.

** **Note:** Part number AX-SWC-PARROT is required (sold separately). Also, the Parrot radio must be updated to rev. 2.1.4 or higher through www.parrot.com.

† **Note:** If you have a Clarion radio and the steering wheel controls do not work, change the radio type to the other Clarion radio type; same for Eclipse. The following section explains how to do this.

‡ **Note:** If you have a Kenwood radio and the L.E.D. feedback comes back as showing as a JVC radio, change the radio type to a Kenwood. The following section explains how to do this.

Configuration Menu

Vehicle Settings
Interface Settings
Language
Version
< Back

Configuration Menu

- The buttons on the steering wheel will be used to operate the configuration menu, which will be shown on the aftermarket radio. To enable the menu, push and hold the Talk button for 2 seconds. Use the Track Up and Track Down buttons to navigate through the menu. To select a menu option, push the Talk button once.

Continued on the next page

SCREEN OPERATION *(CONT.)*

Vehicle Settings

Display
Clock
Doors and Locks
Lights
Safety and Driving Assistance
Vehicle Off Options
< Back

Vehicle Settings

- This is the main settings screen to access the factory settings. All button functions are retained and controlled in the same manner that the factory buttons were controlled. Refer to the vehicle owner's manual for more information.

Interface Settings

Screen Size/Position
Picture Settings
Preferences
<Back

Interface Settings

- This is the main settings screen to access the settings within the interface

Screen Size/Position

Horizontal Size
Horizontal Position
Vertical Size
Vertical Position
< Back

Screen Size/Position

- Make sure all 4 corner markers are touching the corners of the aftermarket radios display.

Continued on the next page

Picture Settings

Brightness
Contrast
Saturation
< Back

Picture Settings

- Adjust brightness, contrast, and color saturation.

Preferences

Park Assist Version 0
Camera Connected Yes
Reverse Priority Park Assist
Park Brake Source Speed
Restore factory settings
< Back

Preferences

- **Park Assist Version** - Select according to the color configuration of the park assist fitted to the vehicle.
- **Camera Connected** - Select "Yes" if an optional backup camera will be installed.
- **Reverse Priority** - Select which image will be shown while the vehicle is in reverse. Options are Camera or Park Assist. The driver can select the desired image by pushing the Source button while in reverse.
Note: This option is only available if "Camera Connected" is set to "Yes".
- **Park Brake Source** - Set to Speed, Brake, or Always On.
- **Restore Factory Settings** - Reverts all interface settings back to factory defaults. This will not restore the vehicle settings.



AX-JP901

INSTALLATION INSTRUCTIONS

Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 7:00 PM

Sunday: 10:00 AM - 4:00 PM



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



**Metra recommends MECP
certified technicians**