Music Playback & Phone Call **Button Controls**

Line vNo.	Desire Result	Require Action	Voice Prompts	Indicator Light	Built-In Motor
1	POWER ON	PRESS "MFB" FOR 3 SEC.	Power on	Blinking White light	Vibrates twice
2	PAIRING MODE*	After Powered ON.	Pairing	Blinking White & Red	
3	CONNECTED	After Paired	Connected	White Blinks /5 sec.	
4	POWER OFF	PRESS "MFB" FOR 3 SEC.	Power off	Red Blinks 3 sec.	Vibrates 1.5 Sec.
5	PRE. TRACK	PRESS "- " FOR 2 SEC.	/		
6	NEXT TRACK	PRESS"+"FOR 2 SEC.	/		
7	VOLUME UP	SHORT PRESS "+"	Max. Alarm		
8	VOLUME DOWN	SHORT PRESS "-"	Min. Alarm		
9	PLAY	SINGLE PRESS MFB	/	White Blinks /5 sec.	
10	PAUSE	SINGLE PRESS MFB	/	White Blinks /5 sec.	
11	IN COMING CALL		/	White Blinks /1 sec.	Vibrating
12	ANSWER CALL	SINGLE PRESS Mic. Button	Voice Beep		
13	END CALL	SINGLE PRESS Mic. Button	Voice Beep		
14	REJECT CALL	DOUBLE PRESS Mic. Button	/		
15	LAST NUMBER REDIAL	DOUBLE PRESS Mic. Button	/		
16	BATTERY LOW		Battery low	Red Blinks	
17	CHARGING		/	Red lights on	
18	CHARGED		/	White lights on	
19	DISCONNECTED		/		
20	AUTO OFF	No connection for 5 min.	/	Red Blinks 3 times	Vibrates 1.5 Sec.

Tchnical Specifications

Earphone type: Wireless Neckband Earphone Bluetooth 4.1

Bluetooth version: Bluetooth chinset: CSR8635 Support incoming call alarm: Vibration

HFP 1.6, HSP 1.2, A2DP 1.3, AVRCP 1.4 Support profile:

Audio decoder: MP3, SBC, AAC iOS Battery Monitor:

Antenna: Ceramic antenna Frequency range: 2.4GHz~2.48GHz

Stereo: For talk and music Frequency response: 20Hz~20 KHz

Frequency range: Dynamic, N45 Neodymium magnet

Speaker diameter: 10mm (0.04in) Speaker impedance: 32Ω ± 15% Max rated power output: 3mW

Operating range:

Sensitivity: THD+N:

Li-lon Polymer 140mAh with fast charge⊠(10min. Charged, 2 hours playback) Music playback time: 10 hours *1

10 hours *1 Talking time: Standby time: 180 hours Charging time: Charging port: Micro USB Type B

Wireless range: 8-10m (26-33ft) [free space] Built-in microphone: -42dB Mic. Sensitivitu:

DC 5V @ 500mA Charging voltage: Do not expose to weather conditions that exceed: -15°C (5°F) ~55°C (131°F) Operating temperature: Bullet type (with S, M, L sizes)

Earbud type: 25g (0.88oz | 0.055lb) Manufacturer Warranty: 1-year limited warranty *2

* This limited warrantu does not cover any damage to the product resulting from improper installation, accident, abuse, misuse, natural disaster, insufficient or excessive electrical supply, abnormal mechanical or environmental conditions, or any unauthorized disa

FAQ

Q: Why won't my NekTek2 earbuds connect to my phone or Bluetooth device? A: Confirm NekTek2 is in Pairing mode and Bluetooth on your phone/device is ON when attempting to connect devices. Occasionally, removing or "forgetting" the NekTek2 Bluetooth connection associated with the device in the device's Bluetooth menu, and then reconnecting the device, can fix this perceived problem with Bluetooth.

Q: My NekTek2 earbuds won't turn on. How can I fix this?

A: Please check the battery status of the earbuds, they could just be out of power. Try connecting them to a power/charging source, waiting 30 seconds, and attempt to turn them on again.

Q: My NekTek2 earbuds appear to not be charging. What can I do to fix this? A: Assure that the charging terminal is plugged tight and otherwise, securely connected. This problem can result from using a different charging cable than the one provided.

O: Can I change the batteru in the NekTek2 earbuds?

A: No, this device uses a built-in, non-removable Li-Polymer battery .

Q: My NekTek2 earbuds have disconnected while I was within the 8-10m (26-33ft) operating range. How can I fix this?

A: Please check if there is metal or other material within a relatively close range, which may interfere with the Bluetooth connection. Bluetooth is a radio technology, which is sensitive to objects between the deadest and the connected device.

Q: I am paired to the headset, why I am not getting any sound output?

A: This could be a problem with the app you are using to play music, check to see if the song has loaded and is playing. Also, assure that the volume on your headset/computer/mobile device is turned up. Separately, please check that the device you are connecting to the earbuds supports

Q: I cannot use the headset to control the volume or for selecting a track or app on my mobile

A: The software settings of the app may vary. Some apps do not support headset control

Safety Information

Thank you for purchasing our new product. Before the first use of the device, we urge you to please read this manual carefully, for your safety. Please pay close attention to, and follow all included warnings and disclaimers, as this will assure you receive the optimal benefit from this

Be aware of the following guidelines when using your headset:

In order to protect person(s) against injury and damage to property, we provide further explanation as to what you should observe below:

 $1. \ \mbox{You should}$ the volume carefully when using this product to prevent hearing damage.

2. Be wary of the environment in which you use this product. Use of this product in severely hot, humid, dusty or corrosive environments can damage and/or impair its functionality. The headset should not be stored or used at temperatures below -15°C (5°F) or above 55°C (131°F) which may shorten headset or battery life.

3. Before using this device, give proper training according to this manual to children and young persons. Thus, you avoid possible accidents. This device is not a toy.

4. Do not use a damaged or incompatible cable to charge or operate this product. This can increase the risk of fire or electric shock; as well as a potential decrease in product performance.

5. Do not disassemble this device. Disassembling this device can lead to complete loss of functionality, a complete void of your warranty, exposure to small or sharp parts, and also may increase the risk of fire or electric shock.

6. Do not use any chemical cleaning solutions or volatile liquids to clean this product. This could

7. Stop using this product if you feel obvious discomfort, irritation, or other adverse reactions.

8. You should avoid turning the volume so high that you can't hear anything around you. If you sense any impairment to your hearing as a result of high-volume use, you should reduce the volume during use or consider not using the product.



California Proposition 65 Warning

WARNING: This product contains chemicals, including lead or lead compounds, that are known to the State of California to cause cancer, and birth defects or

o compuestos de plomo, que son reconocidos por el Estado de California que provocan cáncer, defectos de nacimiento u otros daños reproductivos.

www.nvx.com

Copyright © 2018 Limitless Creations LLC.

All rights reserved. Designed in Kentucky. Assembled in China.


Warranty void if serial number label is altered or removed. 1-year warranty

NVX and the NVX logo are registered trademarks of Limitless Creations LLC.

All other brand names are trademarks or registered trademarks of their respective owners.

(€ | 🗸 | 👸 | 🗵

For more information, please visit; www.P65Warnings.ca.gov









Built-in Call Vibration Motor



Hands Free



Supporting Fast Charge and Up to 0 Hours Battery Life



Magnetic Ear Buds





Turn on Bluetooth from the Bluetooth menu in your device.



Go to Settings > Bluetooth. Move the Bluetooth slider to ON A list of Bluetooth devices will appear. Choose the option closest related to your model of earbuds (such as NVX NekTek2) in the list to connect.



Go to Settings > Wireless & Networks > Bluetooth settings. Check the box next to Bluetooth to turn Bluetooth on. A list of Bluetooth-ready devices will appear.

Choose the option closest related to your model of earbuds (such as NVX NekTek2) in the list to connect.

Connect to NekTek2

Press the MF button until the WHITE LED light blinks and motor vibrates twice to signify a Power ON. This may take multiple presses of the button.

After the earbuds are powered on, the NVX NekTek2 is ready for pairing.

Hold the MF button until the RED and WHITE LED lights begin blinking, find the NVX NekTek2 in the Bluetooth menu of your device and select it to pair Bluetooth.

In connection mode (successfully connected), the WHITE LED lights will blink every 5 seconds. The headset will Power OFF automatically if disconnected for 5 minutes without attempt to pair to Bluetooth.

* Earbuds must be charged or connected to a power source to Power ON

** Earbuds must have paired to the Bluetooth-ready device you plan to automatically pair to at least once prior to allow for seamless automatic pairing the next time.



Start Listening

Your NekTek2 Wireless Neckband Earphones are now connected and ready to use.



Remote Controls

Control music, manage calls and adjust volume with the

Music Play/Pause: Press the MF button once to play/pause

Volume adjustment/Music selection:

Press Vol (+) and Vol (-) once to adjust volume; Press and hold the Vol (+) [next track] and Vol (-) [previous track] for 2 seconds to navigate previous/next track.

When there is an incoming call, press the Microphone button to answer the call, or use your mobile device to answer it.

Reject incoming call:


When there is an incoming call, double press the Microphone button to reject the call, or use your mobile device to reject it.

Single press the Microphone button, or use your mobile device

to hang up your call.

Last call redialing:

In Standby mode, double press the Microphone button to redial your last call.





blinks 3 times and goes out and built-in motor vibrates for about 1.5

NekTek2

User Guide

Wireless Neckband Earbuds

Charging time of the headset takes approximately up to 40 minutes

Using charging accessories from a different manufacturer, or charging accessorie with different power specifications is not recommended, and could result in a noticeable difference in charging performance and/or irregularities in product